



Advanced Composite Technology

50 Pine Road, Brentwood, NH 03833

Phone: 603/778-8899

Fax: 603/778-7455

e-mail: nei@nei-act.com

August 31, 2011

Dave Hager
c/o Boral Roofing
7575 Irvine Center Drive, Suite 100
Irvine, CA 92618

Dear Mr. Hager,

NEI requires that all Oriented Strand Board (OSB) must be primed with an asphalt based primer before application of any of our self-adhered underlayments/membranes when applied directly to the roof deck. Mechanically fastened base sheets or underlayments do not require priming of the OSB.

Priming is not required when the tile or final roof covering is to be mechanically fastened through the underlayment to the deck. The underlayment must be rolled or stiff broomed into place to ensure maximum adhesion to deck. Back nailing of the selvedge lap is required.

Please let me know if you have any further questions. Thank you.

Sincerely,

A handwritten signature in blue ink, appearing to read 'Elizabeth Butler', with a long, sweeping horizontal line extending to the right.

Elizabeth Butler
Sales & Marketing Manager
Northern Elastomeric Inc.